

# FINISHING MOTOR Operation Manual


Thank you for having purchased our "FINISHING MOTOR". Please read this manual carefully before use. This manual should be retained in a place accessible for future reference.



**CAUTION** 

●Use this product for rod finishing purpose only. ●Do not use with any power voltage other than the indicated voltage. •Do not make high impact to this product by dropping or banging. It may cause damage.

■Keep out of reach of children.
■Do not attempt to disassemble or alter this product. It may cause malfunction. OCheck condition of this product before use and confirm safety.




#### How to assemble

#### 1. How to assemble Chuck

Insert the tube to this point



- 6 Chuck. (2 sets)Enable smooth insertion with dipping into soapy water.



# 4. How to assemble Rod Stand




Peel off film of 4 Felt Tape and stick it to 3 Protector.


Then, gently push Protector into V-shaped slit of 2 Rod Stand until it clicks.

# 2. How to attach Chuck to Joint

Attach Chuck with (5) Joint. As shown below, insert until the ring shape touch to Joint. (2  ${\overline{\mathcal{T}}}$  Insert Rod Protection Tube to sets)  ${\overline{\mathbb{X}}}$ Be aware of insert direction.




### 3. How to attaching to Motor Stand



Clasp assembled Joint with 1 Motor Stand.


Be aware of position of 9 Screw clamp.

# 5. How to attach Earth Cable



Attach (8) Earth Cable to plain side of Motor Stand with 9~12 Screw. Washer and Nut.

#### (Completion)




Cable length is shown shorter than actual.

# Operation

# 1. How to hold rod

Chuck is opened and closed by pushing as below, and it grasps rod.



※ "I" means power-on.

# Maintenance

- •Do not use chemicals such as thinner for cleaning. •Keep every parts clean and use caution to avoid catching foreign material into rotating part. •Scrubbing with hard or sharp material may cause scratch or damage.
- •Do not tug or bent cable. It may cause loose connection or disconnection.

# 2. Power Activation

Rotation direction changes every time you turn on the power. Turn on and off the power until it rotates desired direction. ● Applicable to rod with diameter 4mm - 30mm and less than 500g. ● If you operate t product with light weight blank, blank may not stay on V-shaped slit due to eccentricity. 

Although this product is introduced some measures to protect blank, there is still possibility that it would scratch blank.



CAUTION

Follow this manual and assemble product safely. In case assembled incorrectly, this product would be damaged or malfunctioned caused by rotating failure. 

Do not place this product in any place where it will be subjected to direct sunlight, high temperatures or close to fire.



CAUTION

Do not splash water on this product or touch with wet hand. There is possibility of electrical shock. Oconnect earth cable before turning on the power.



CAUTION

Do not touch rotating part during operation. It may cause injury by catching a part of body or clothes.

# FUJI KOGYO.CO.,LTD

〒422-8564 静岡市駿河区南町19-3 TEL(054)285-2251